

# Gus's Kitchen and Bath

[www.guskitchenandbath.com](http://www.guskitchenandbath.com)

1292 Highway 7 East, Keene, Ontario, K9J0G6

Phone: 705-295-4335 or 705-876-6030

Fax: 705-876-6951

Email: [info@guskitchenandbath.com](mailto:info@guskitchenandbath.com) or [wendy@guskitchenandbath.com](mailto:wendy@guskitchenandbath.com)



## Installation instructions for undermount sinks and granite tops

\*Required for installation – 100% clear kitchen and bath silicone

### Undermount Sinks

- Turn the granite upside down
- Place a bead of silicone on the lip of the sink
- Adhere the sink to the underside of the granite top
- Please a second bead of silicone on the outer rim of the sink
- Allow to dry

Granite Tops - We recommend sealing the granite top with any good granite sealer

- Place a bead of silicone along the outside edges of the vanity
- Position the granite top onto the vanity ensuring a 1//2" overhang on each end
- Allow to dry

### Back -Splash

- The back-splash is secured in the same fashion
- Use a bead of silicone along the bottom of the back-splash
- Position the back-splash along the back edge of the granite top
- Allow to dry

### 60" Double Sink Vanities

Some cutting of wood may be necessary for the fitment on the sinks using a jigsaw.

If you have any trouble with the installation of the sinks into the 60" vanities, please call Gus at 705-295-4335