

One Touch Seat Installation P.1



Parts List:

- Toilet Seat
- 2x Stainless Caps
- 2x Seat Connections with peg]
- 2x Rubber Gasket for non-slip
- 2x Metal Screws and Washers



<--Fully Assembled Holding Stem (example)



- Clean area around seat hole
- Fit rubber gasket on bottom of seat connections
- Place seat connections over hole and feed screw through
- With screwdriver on top, secure nut to bottom of screw
- Use pliers underneath to hold nut until seat connection is almost tight



One Touch Seat Installation P.2



-Before tightening nut fully, place toilet seat on movable connectors so that you can center the seat left to right

-Once seat is in place, gently press button and remove seat to finish tightening screw/nut fully.



-Finished screw should be tightened beyond movement